

PLUS100 PAN

CONTROL SYSTEM FOR DOUGH-RETARDERS



Use and maintenance manual

READ AND KEEP

CONTENTS

INTRODUCTION

Page 4	1.1	General
Page 4	1.2	Product ID codes
Page 5	1.3	Overall dimensions
Page 5	1.4	Identification data

CHAP. 1

INSTALLATION

Page 6	2.1	Important information for installer
Page 6	2.2	Standard assembly and use kit

CHAP. 2

FUNCTIONS

Page 7	3.1	Functions managed by the PLUS100 PAN
--------	-----	--------------------------------------

CHAP. 3

TECHNICAL CHARACTERISTICS

Page 8	4.1	Technical characteristics
Page 9	4.2	Warranty terms

CHAP. 4

PARAMETER PROGRAMMING

Page 10	5.1	Control panel
Page 11	5.2	LCD display
Page 12	5.3	General features
Page 12	5.4	Key to symbols
Page 12	5.5	Setting and displaying the set-points
Page 13	5.6	Level 1 programming
Page 14	5.7	List of Level 1 variables
Page 15	5.8	Level 2 programming
Page 16	5.9	List of Level 2 variables

CHAP. 5

USING THE UNIT

Page 18	6.1	Cold/hot: maintaining room temperature
Page 18	6.2	Humidifying/dehumidifying: maintaining room humidity
Page 19	6.3	Ventilation
Page 19	6.4	Air changeover
Page 19	6.5	Clock / calendar
Page 20	6.6	Manual cycles
Page 21	6.7	Automatic cycles
Page 25	6.8	Supervision/monitoring system TeleNET

CHAP. 6

TROUBLESHOOTING

Page 26	7.1	Alarms: description and procedures
Page 27	7.2	Troubleshooting guide

CHAP. 7

APPENDICES

Page 29	A.1	EU declaration of conformity
Page 30	A.2	PLUS100 PAN connections diagram

CHAPTER 1: INTRODUCTION

1.1**GENERAL**


The **PLUS100 PAN** system allows the user to control temperature and humidity. The system consists of the **100N MASTER** unit, on which all the electrical connections are made, and the **PLUS100 PAN** control panel, which features a large LCD display to provide rapidly available, complete information on room status. The system allows the user to cool, heat and ventilate the room, switch the room light on/off, humidify it, effect an air changeover, dehumidify it, defrost it and control alarms.

1.2**PRODUCT ID CODES****PLUS100 PAN**

Control of temperature and humidity for pause-leavening applications.

OVERALL DIMENSIONS

1.3



IDENTIFICATION DATA

1.4

The unit described in this manual has, on its side, an ID plate showing all the relevant identification data:

- Name of Manufacturer
- Code of the electrical board
- Serial number
- Power supply voltage



CHAPTER 2: INSTALLATION

2.1

IMPORTANT INFORMATION FOR THE INSTALLER

1. Install the device in places where the protection rating is observed and try not to damage the box when drilling holes for wire/pipe seats.
2. Do not use multi-polar cables in which there are wires connected to inductive/power loads or signalling wires (e.g. probes/sensors and digital inputs).
3. Do not fit power supply wiring and signal wiring (probes/sensors and digital inputs) in the same raceways or ducts.
4. Minimise the length of connector wires so that wiring does not twist into a spiral shape as this could have negative effects on the electronics.
5. Fit a general protection fuse upstream from the electronic controller.
6. All wiring must be of a cross-section suitable for relevant power levels.
7. When it is necessary to make a probe/sensor extension, the wires must be of the correct cross-section, which in any case must be at least 1mm².

2.2

STANDARD ASSEMBLY AND USE KIT

The **PLUS100 PAN** system is supplied with the following assembly and utilisation items:

n°2 temperature sensors
n°1 fixing bracket
n°1 telephone plug lead
n°1 user's manual

CHAPTER 3: FUNCTIONS

3.1

FUNCTIONS CONTROLLED BY THE PLUS100 PAN

- Display and adjustment of temperature and humidity settings (neutral zone).
- Activation/deactivation of stand-by mode.
- Sensor alarm/warning signals.
- Adjustment of differential temperature and humidity parameters.
- Adjustment of air changeover control parameters.
- Adjustment of defrosting parameters.
- Adjustment of fan parameters.
- Display of output status.
- Simultaneous display of temperature and humidity values.
- Automatic program management with automatic variation of temperature and humidity settings over time.
- Clock function.

CHAPTER 4: TECHNICAL CHARACTERISTICS**TECHNICAL CHARACTERISTICS****4.1**

Power supply		
Voltage	230 V~ ± 10% 50/60 Hz	
MAX power absorption	~ 8 VA	
Climatic conditions		
Working temperature	-10 – 60 °C	
Storage temperature	-30 – 70 °C	
Relative humidity	below 90% RH	
Input characteristics		
Analogical inputs	NTC 10K 1% 4...20 mA	Temperature sensor Humidity sensor
Read resolution	1°C 1 RH%	Temperature Humidity
Sensor read precision	± 0.5 °C see characteristics of humidity sensor	
Read range	-45...+45 °C 0...99 RH%	
Output characteristics		
Outputs on relay	1 output on terminal N.A. 30A (AC1) 230VAC 9 outputs on terminal N.A. 16A (AC1) 230VAC	
Dimensional characteristics		
100N MASTER box dimensions (mm)	121,5 x 71 x 175	(HxDxL)
PLUS100 PAN keypad box (mm)	98 x 35 x 180	(HxDxL)
Insulation characteristics		
Keypad protection rating	IP55	

PLUS100 PAN series products are covered by a 24-months warranty against all manufacturing defects as from the date indicated on the product ID code.

In case of defect the product must be appropriately packaged and sent to our production plant or to any authorized Service Center with the prior request of the Return Authorization Number.

Customers are entitled to have defective products repaired, spare parts and labour included. The costs and the risks of transport are at the total charge of the Customer. Any warranty action does not extend or renew its expiration.

The Warranty does not cover:

- Damages resulting from tampering, impact or improper installation of the product and its accessories.
- Installation, use or maintenance that does not comply with the instructions provided with the product.
- Repair work carried out by unauthorized personnel.
- Damage due to natural phenomena such as lightning, natural disasters, etc...

In all these cases the costs for repair will be charged to the customer.

The intervention service in warranty can be refused when the equipment is modified or transformed.

Under no circumstances **Pego S.r.l.** will be liable for any loss of data and information, costs of goods or substitute services, damage to property, people or animals, loss of sales or earnings, business interruption, any direct, indirect, incidental, consequential, damaging, punitive, special or consequential damages, in any way whatsoever caused, whether they are contractual, extra contractual or due to negligence or other liability arising from the use of the product or its installation.

Malfunction caused by tampering, bumps, inadequate installation automatically declines the warranty. It is compulsory to observe all the instructions in this manual and the operating conditions of the product.

Pego S.r.l. disclaims any liability for possible inaccuracies contained in this manual if due to errors in printing or transcription.

Pego S.r.l. reserves the right to make changes to its products which it deems necessary or useful without affecting its essential characteristics.

Each new release of the Pego product user manual replaces all the previous ones.


As far as not expressly indicated, is applicable the Law and in particular the art. 1512 C.C. (Italian Civil Code).

For any controversy is elected and recognized by the parties the jurisdiction of the Court of Rovigo.

CHAPTER 5: PARAMETER PROGRAMMING

CONTROL PANEL


5.1



1. LCD display.
2. Automatic cycle progress bar.
3. Cycle START/STOP (hold for a few seconds to start or stop an automatic cycle) / Timer (press once to show day and time of end of cycle in progress).
4. UP (**Automatic cycle programming**).
5. Stand-by (system at standstill, does not interrupt cycle in progress).
6. SET temperature / SET humidity (press successively to alternate temperature and humidity).
7. DOWN, **forced defrosting**, alarm mute.
8. Room light.

5.2

LCD DISPLAY



1. Progress of PHASE 1 (**cooling** duration set by final user, physically occupies sectors n° 1, 2, 3, 4, 5).
2. Progress of PHASE 2 (**maintenance**, so-called elastic phase, physically occupies sectors n° 6, 7, 8, 9, 10).
3. Progress of PHASE 3 (**leavening**, duration set by final user, physically occupies sectors n° 11, 12, 13, 14, 15, 16).
4. Progress of PHASE 4 (**product ready settling**, max. duration 4 hours, occupies the last sectors n° 17, 18, 19, 20).
5. Relative ambient humidity / parameter values / error codes.
6. Ambient temperature / parameter values.
7. Programming (controller is in programming mode).
8. Cooling (flashes if called for dehumidification only).
9. Heating (flashes if called for dehumidification only).

10. Humidification.
11. Dehumidification.
12. Defrosting.
13. Evaporator fans (both high and low speed).
14. Light.
15. Alarm.
16. Stand-by (light on continuously - controller ON, light flashing, controller in STAND-BY).
17. Time / date / time parameter values.

5.3**GENERAL**

To enhance safety and simplify the operator's work, the **PLUS100 PAN** system has two programming levels; the first level (Level 1) is used to configure the frequently-modified SET-POINT parameters. The second programming level (Level 2) is for general parameter programming of the various controller work modes.


It is not possible to access Level 2 programming directly from Level 1: you must exit the programming mode first.

5.4**KEY TO SYMBOLS**


For purposes of practicality the following symbols are used:

- (▲) the UP key is used to increase values and in **programming the cycles**;
- (▼) the DOWN key is used to decrease values and mute the alarm.

5.5**SETTING AND DISPLAYING THE SET-POINTS**

1. Press the **SET key**  to display the current **SET-POINT** (temperature or humidity).
2. Hold down the **SET key** and press the (▲) or (▼) keys to modify the **SET-POINT**.
3. Release the **SET key** to return to room temperature display: the new setting will be saved automatically.

To gain access to the Level 1 configuration menu proceed as follows:

1. Press the (▲) and (▼) keys simultaneously and keep them pressed for a few seconds until the first programming variable appears on the display.
2. Release the (▲) and (▼) keys.
3. Select the variable to be modified using the (▲) or (▼) key.
4. When the variable has been selected it is possible:
 - Display the setting in the respective sector of the display (5 or 17 page 11).
 - To modify the setting by pressing the SET key  and the (▲) or (▼) keys.

When configuration values have been set you can exit the menu by pressing the (▲) and (▼) keys simultaneously for a few seconds until the room temperature reappears; alternatively, do not press any key for a few seconds.

5. The new settings are saved automatically when you exit the configuration menu.

5.7

LIST OF LEVEL 1 VARIABLES (User level)

LABEL	MEANING	RANGE	DEFAULT
d-t	Temperature difference compared to main SET-POINT	1÷10 °C	2°C
d-U	Differential for Humidification compared to main SET-POINT	1÷10 rH%	5 rH%
d-d	Differential for Dehumidification compared to main SET-POINT	1÷10 rH%	5 rH%
d0	Air changeover interval (parameter only active during the leavening phases)	00...24 hours	0:00
d1	Air changeover duration (parameter only active during the leavening phases)	1...60 min	6 min
d4	Defrosting interval, interval between one defrosting and the next d4=0 no defrosting. (parameter only active during cooling and maintenance stages)	0..24 hours	8 hours
d5	Max defrost duration time	1..60 min	20 min
d6	End of defrosting temperature SET-POINT. Defrosting is not executed if the temperature read by the defrosting sensor is higher than the end of defrosting setting. (in the event of a faulty sensor defrosting is timed)	-35 ÷ 45 °C	12°C
F5	Fan stop time (Expressed in minutes) At the end of defrosting the fans can be kept at standstill for a further set time. This time begins at the end of defrosting (parameter active only in the cooling and maintenance phases)	0 - 10 min	2 min
F6	Fan shutdown temperature. (Expressed in °C.) At the end of defrosting or at start-up the fans can be kept at standstill until the evaporator sensor temperature setting is reached. (parameter active only in the cooling and maintenance phases)	-20 ÷ 30 °C	23 °C
tEu	Defrosting sensor temperature display (evaporator)	--	Read only
DMy	Current date	dd:mm:yy	
HMS	Current time	0:00 .. 23:59 hh:mm	

To access the second programming level press the UP (▲) and DOWN (▼) keys and the

LIGHT  key simultaneously for a few seconds.

When the first programming variable appears the system automatically goes to stand-by.

1. Select the variable to be modified by pressing the UP (▲) and DOWN (▼) keys.

When the parameter has been selected it is possible to:

2. View the setting in the respective sector of the display (5 or 17, page 11).

3. Modify the setting by holding the SET key  down and pressing the (▲) or (▼) key.

4. When configuration settings have been completed you can exit the menu by pressing the (▲) and (▼) keys simultaneously and keeping them pressed until the room temperature value reappears.

Exit from Level 2 is not automatic, even if keys are left untouched for a long time.

5. Changes are saved automatically when you exit the configuration menu.

6. To enable the electronic controller press the STAND-BY key .

5.9

LIST OF LEVEL 2 VARIABLES (Installer level)


LABEL	MEANING	RANGE	DEFAULT
AC	Door switch input status	0 = NO 1 = NC	0
C1	Minimum time between compressor shutdown and subsequent switching on	0...15 min	0 min
Ad	Network address for connection to the TeleNET system	0÷31	0
dEU	Dehumidification mode select. Separate dehumidification calls heat/cold by temperature only	0 = cooling 1 = heating 2 = separated dehumidification	2
EnU	Humidification enable	1 = enabled 0 = disabled Humidification control only executed during leavening and settling phases.	1
End	Dehumidification enable	1 = enabled 0 = disabled Humidification control only executed during leavening and settling phases.	1
CAt	Ambient sensor value correction	-10...+10 °C	0 °C
CAU	Humidity sensor value correction	-20...+20 rH%	0 rH%
St1	First leavening step temperature set-point	0...+45 °C	5 °C
SU1	First leavening step humidity set-point	50...99 rH% (50%=humidity not controlled)	85 rH%
t1	First leavening step duration hh:mm	00:00...2:00 hh:mm	00:30
St2	Second leavening step temperature set-point	0...+45 °C	10 °C
SU2	Second leavening step humidity set-point	50...90 rH% (50%= humidity not controlled)	80 rH%
t2	Second leavening step duration hh:mm	00:00...2:00 hh:mm	00:30
St3	Third leavening step temperature set-point	0...+45 °C	16 °C
SU3	Third leavening step humidity set-point	50...99 rH% (50%= humidity not controlled)	80 rH%
t3	Third leavening step duration hh:mm	00:00...2:00 hh:mm	00:30
St4	Fourth leavening step temperature set-point	0...+45 °C	16 °C

SU4	Fourth leavening step humidity set-point	50...99 rH% (50%= humidity not controlled)	80 rH%
t4	Fourth leavening step duration hh:mm	00:00...2:00 hh:mm	00:00
St5	Fifth leavening step temperature set-point	0...+45 °C	16 °C
SU5	Fifth leavening step humidity set-point	50...90 rH% (50%= humidity not controlled)	80 rH%
t5	Fifth leavening step duration hh:mm	00:00...2:00 hh:mm	00:00
Hr	Humidity control	Hr = 1 humidity control enabled Hr = 0 humidity control disabled Humidity sensor can be disconnected without error, the display shows evaporator sensor instead of humidity (if dE=0)	1
dE	Evaporator sensor exclusion	0 = sensor present 1 = sensor absent	0
EnC	Enables cold (cooling) during manual, automatic leavening and settling.	0 = cold disabled 1 = cold enabled	1
Str	Settling phase temperature set-point	0...+45 °C	12 °C
SUr	Settling phase humidity set-point	50...99 rH%	80 rH%
d9	Defrost enable during cooling	0 = defrosting disabled 1 = defrosting enabled	0

CHAPTER 6: USING THE UNIT

6.1

COLD/HEAT: MAINTAINING AMBIENT TEMPERATURE


Heating/cooling is neutral-zone controlled on the basis of the temperature set-point (key 6 ) and the temperature differential (parameter d-t).

Cooling is activated when the set + differential threshold is passed and stays on until the set-point is reached.

Heating is activated when the setting – differential threshold is reached and stays on until the set-point is reached.

6.2

HUMIDIFICATION/DEHUMID. : MAINTAINING AMBIENT HUMIDITY

Humidity and dehumidification are neutral-zone controlled during the leavening, maintenance and settling phases only, and only if the programmed set-point is greater than the settable minimum (**50%**)* on the basis of the humidity set-point (key 6 ) and the differential for Humidification (parameter d-U) and differential for Dehumidification (parameter d-d).

Humidification is activated below the **set – differential for Humidification (parameter d-U)** threshold and stays on until the set-point is reached.

Dehumidification is activated above the **set + differential for Dehumidification (parameter d-d)** threshold and stays on until the set-point is reached.

Humidity control can be disabled via the Hr (relative humidity) parameter, or by setting the set point to the minimum R.H.% 50 = humidity control disabled (display only).

Dehumidification alone be disabled via the End parameter.

Humidification alone can be disabled via the EnU parameter.

There are three dehumidification modes (dEU parameter):

1. Dehumidification with cooling (cold is called to dehumidify, heat is added only to maintain ambient temperature).
2. Dehumidification with heating (heat is called to dehumidify, cold is added only to maintain ambient temperature).

If the difference in temperature is, with respect to the setting, greater than 5°C (during dehumidification with the compressor and elements) 5°C, the unit with the

greater value shuts down to prevent any overheating or over-cooling which could damage the product.

3. Separated dehumidification (dehumidification output activated only but without cold/heat call).

(*) if the humidity set point is set to the minimum (50%) neither dehumidification nor humidification are controlled

VENTILATION

6.3

Fan speed is regulated by two digital outputs (high/low speed) and run at high speed with the cold call during the cooling and maintenance phases and continuously at low speed during the leavening and settling phases.

Fans are always off during defrosting.

Variants can be controlled via parameters F5 and F6.

AIR CHANGEOVER

6.4

Air changeover is controlled via parameters d0 and d1.

Use d0 to establish the interval between one air changeover and another: the counter starts its count from zero at the start of every manual or automatic leavening cycle. If d0=00 no air changeover is carried out.

Use d1 to establish the duration of the air changeover.

Cooling, heating, humidification and dehumidification are not activated during air changeover.

CLOCK / CALENDAR

6.5

Current time and date can be adjusted via the dMY and HMS parameters.

The current time is shown on the LCD display.

The controller recognises the manual cycles (only hot or only cold) from the temperature setting only when in stop mode, not in stand-by.

If the set-point is less than or equal to 10°C the controller recognises the manual cold cycle. It will consequently run the fans simultaneously with the compressor call and execute the programmed defrosts as per the parameter settings; humidity control will not be executed.





If the set-point is higher than 10°C the controller recognises the manual hot cycle.


Consequently the fans are run continuously, humidity is controlled according to the RH% setting and the defrost cycles are not executed.


6.7

AUTOMATIC CYCLES

It is possible to set four automatic pause-leavening cycles each with fully independent automatic programmed leavening, and a maintenance-only cycle (riC 0) with cooling start. The four cycles have the following characteristics: cycle n°1 is carried out the same day (12 hrs); cycle n°2 is for the next day (24 hrs); cycle 3 for the second successive day (48 hrs); and cycle 4 for the third successive day after the (72 hrs).

To enter the recipes programming mode press key 4  until the letters **riC** appear on the temperature display and the numbers **01 ... 04** on the RH% display. Use keys 4  and 7  to select the recipe to be programmed, press key 3  to enter programming mode for the selected recipe. The 20 segments at the top of the unit should all be off: only one of the first four will remain on to remind you of the recipe you are programming. To program the data proceed as follows:




1. Use the (**▲**) or (**▼**) key to select the variable to be modified. After selecting the desired variable it will be possible to:
2. View the value on the respective sector of the display (5 or 17 page 11).
3. Modify the setting by pressing or maintaining the SET key  and pressing the (**▲**) or (**▼**) key.

Exit programming mode [from the product ready day window (LI6) by keeping key 4  pressed for 2 seconds; in any case the unit will exit programming mode if no keys are touched for 30 seconds.


CYCLE PROGRAMMING DATA:

DISPLAY TEMP.	DISPLAY RH%	DISPLAY TIME	Default recipe 1	Default recipe 2
AC1	Cooling temperature -20°C.....0°C.	Off	-7	-10
AC2	Off	Cooling time 00:00:00.....29:59:00	04:00:00	05:00:00
Co1	Maintenance temperature -5°C.....15°C.	Off	-2	-4
Co2	Hr% Maintenance 50%....99.0%	Off	50	50
Li1	Final leavening temp. 10°C.....+45°C.	Off	27	30
Li2	Off	Leavening duration t1+t2+t3+t4+t5..09:59:00	04:00:00	05:00:00
Li3	Final leavening RH% 50%....99.9%	Off	80	85
Li4	Off	Product ready time 00:00....23:59:00	02:00:00	02:30:00
Li5	End-of-cycle settling 1 = Yes 0 = No	Off	0	0
Li6	Off	Product ready day 01:01:04....31:12:99 (read only)	/	/

N.B. the 00 cycle is dedicated to a cool-only cycle that consists of an initial cooling phase followed by a switch to maintenance for an indefinite period; the programmable data items for this recipe are therefore: **AC1; AC2; Co1; Co2.**

Once programming has been completed you can start a cycle by pressing key 3  for a few seconds. The display asks which recipe is to be used (riC 00 ... riC 04). Select the desired recipe via the up/down keys: when key 3  is pressed again the product ready (oven-ready) time and day are displayed for 5 seconds. If the shown data is correct there is no need to carry out any further tasks and the controller makes subsequent checks and then starts the cycle. If, however, the data is incorrect stop the cycle by pressing key 3 , enter the recipe, modify the incorrect data and restart the cycle.

The controller makes a quick calculation to see if the cycle duration time is compatible with the "product ready" time and day. If everything is compatible the cycle begins and the first segment lights up. If, instead, there are incompatibilities the controller goes to stand-by, the buzzer sounds and the **EP** message appears on the display to indicate erroneous

programming. To switch off the buzzer press key 7 . The progress of the cycle is highlighted at the top of the unit as follows:


Phase 1: cooling n° 5 segments;


Phase 2 maintenance n° 5 segments;


Phase 3 leavening n° 6 segments;


Phase 4 settling (where enabled) n° 4 segments.

If a settling phase is enabled sector 19 will light up at the cycle **START** to remind the user that, when the product ready time is reached, the cycle will be completed by a settling phase. It goes off at the start of the settling phase (i.e. when segment n° 17 lights up).

While a complete cycle is being carried out the number of the recipe “**riC 01**” can be viewed on the RH% display and the baking day/time displayed alternately on the clock display (17) for a few seconds by pressing key 3  briefly. While a complete cycle is in

progress you can view and modify the recipe in use by pressing key 4  for 2 seconds: you can vary temperature and humidity **but not the duration times of the different stages.**

At the end of the final leavening cycle (if settling is not enabled) the controller goes to stand by. The buzzer sounds and the segment bar flashes to indicate that the cycle is over. Buzzing/flashing stops automatically after 1 minute or when key 7  is pressed.

The user can vary temperature and humidity set-points alternately at any time during the active cycle (manual heat/cool cycles included) via key 6 : note, however, that during a complete cycle variation of the set-point is relative to the phase in progress.

The first phase is known as cooling (cold is produced and “accumulated”). If the recipe has a cooling time of 0:00 the controller immediately goes to the maintenance phase at the start of the cycle.

There then follow: maintenance, intermediate leavening, final leavening and (where enabled) settling.

N.B. the end of the cycle (Li4 - product ready time) is defined by the end of the final leavening phase, not the settling cycle.

The cooling phase is characterised by:

- Temperature set-point
- Duration of the phase

The maintenance phase is characterised by:

- Temperature set-point
- Humidity set-point

The leavening phase is characterised by:

- Temperature set-point
- Humidity set-point
- Duration of the intermediate leavening phases via 2nd level parameters and overall leavening duration programmed by final user. N.B. overall leavening duration can never be less than the sum of the 5 parameter-programmed steps.


The settling phase is characterised by:

- Duration in hours (2nd level parameter)
- Temperature set-point (2nd level parameter)
- Humidity set-point (2nd level parameter)

If a phase has time 0, it is not executed and the controller goes to the next phase.


Phase times continue even in the event of an electrical power failure or controller stand-by.

When an automatic cycle is in progress it is possible to check the number of the cycle in

use and the in-oven day / time by briefly pressing key 3  (CYCLE START); sector 17 of the display (DATE TIME) shows first day and then time.

The **TeleNET** supervision system allows the user to create a historical room temperature and humidity database via Personal Computer.

To configure the instrument, refer to the **TeleNET** manual.



Assign the PLUS100 PAN system address via the configuration sequence by selecting the **Ad** label from the 2nd programming level (installer level) and following the normal address attribution criteria used for **TeleNET**.

Temperature as detected by the controller can be displayed at the **TeleNET** address **Ad+1** by setting the module as TWMT (temperature acquisition module).

In this way the **TeleNET** supervision program can simultaneously display temperature and relative humidity as measured by the PLUS100 PAN and build up a record of both parameters.

Example: if parameter **Ad** is set to **3**, relative humidity can be displayed on the **TeleNET** by assigning the TWMUR module to address 3; temperature can be displayed by assigning address 4 (obtained by summing one to the parameter $Ad=3$) as the TWMT module.

N.B. The address **Ad+1** can, in any case, be used by any device connectable to the **TeleNET** (in place of PLUS100 PAN temperature display) except for TWMT modules to which a different address must be assigned so as to avoid any conflict.

CHAPTER 7: TROUBLESHOOTING

7.1

ALARMS: DESCRIPTION AND PROCEDURES

In the event of any anomalies the **PLUS100 PAN** system warns the operator by displaying alarm codes and sounding the warning buzzer inside the control panel. If an alarm is tripped the display will show one of the following messages:

ALARM CODE	POSSIBLE CAUSE	PROCEDURE TO BE FOLLOWED
E0	Temperature sensor not working properly (stops the system)	<ul style="list-style-type: none"> • Check the temperature sensor. • If the problem persists contact the technical assistance service.
E1	Humidity sensor not working properly (stops humidity control)	<ul style="list-style-type: none"> • Check the humidity sensor. • If the problem persists contact the technical assistance service.
E2	Evaporator sensor not working properly (defrostings scheduled)	<ul style="list-style-type: none"> • Check the evaporator sensor. • If the problem persists contact the technical assistance service.
E3	EEPROM ALARM EEPROM memory error detected. (all outputs deactivated)	<ul style="list-style-type: none"> • Switch off unit and switch back on. • If the problem persists change the control board.
E4	Software compatibility error	<ul style="list-style-type: none"> • Check for correct match between MASTER board and control panel board.
E6	Flat battery	<ul style="list-style-type: none"> • Contact the technical assistance service to have the battery replaced.
EC	Compressor safeguard (e.g. overheat or excess pressure). (Compressor and dehumidification output deactivated if parameter dEU = 0 or 1)	<ul style="list-style-type: none"> • Check compressor status. • Check compressor absorption. • If the problem persists contact the technical assistance service.
En	No connection between control panel and control board	<ul style="list-style-type: none"> • Check connections between the two units. • Check for presence of ferrite on sensors. • If the problem persists contact the technical assistance service.
EP	Erroneous recipe programming (goes to stand-by)	<ul style="list-style-type: none"> • Check recipe duration with product-ready time and day at the moment of cycle START.
EU	Humidifier alarm (relevant output does not deactivate)	<ul style="list-style-type: none"> • Check specific alarm type on humidifier control.
EF	Fan overheat safety device (relevant output not deactivated)	<ul style="list-style-type: none"> • Check fan absorption. • If the problem persists contact the technical assistance service.

TROUBLESHOOTING GUIDE

7.2

PROBLEM	PROBABLE CAUSE	PROCEDURE TO BE FOLLOWED
The Control Panel does not respond and the display is blank	Power supply fault (check connection lead to control board). Control board power supply not connected. Incorrect connection between Control Panel and Control Board (Panel power supply probably inverted with RS-485 signal)	<ul style="list-style-type: none"> • Check that power arrives at the Panel and/or Control Board terminals. • Check connections between Control Panel and Control Board. • If the problem persists contact the technical assistance service.
The Control Panel does not respond and the display reads En	Incorrect connection between Control Panel and Control Board. Connection between Control Panel and Control Board interrupted	<ul style="list-style-type: none"> • Invert RS-485 signal lead connection. • Check connections for continuity.
The PLUS100 PAN system generates false alarms	Sensor(s) connected incorrectly or faulty	<ul style="list-style-type: none"> • Check all connections. • Check Control Board connection leads for continuity. • If the problem persists contact the technical assistance service.
The humidity sensor does not display the correct humidity value	Sensor is not connected properly. Correct type of humidity sensor not selected.	<ul style="list-style-type: none"> • Check that sensor is working properly and that connection is correct.
The PLUS100 PAN system does not respond to the parameters set on the configuration	Incorrect parameter settings	<ul style="list-style-type: none"> • Check the system configuration settings.
The PLUS100 PAN system does not dialogue with the TeleNET	Connection of PLUS100 PAN system to the TeleNET module network has not been made correctly	<ul style="list-style-type: none"> • Check the connection to the TeleNET network. • Check attributed address.

APPENDICES

A.1

UE DECLARATION OF CONFORMITY

LA PRESENTE DICHIARAZIONE DI CONFORMITA' E' RILASCIATA SOTTO LA RESPONSABILITA' ESCLUSIVA DEL FABBRICANTE:
THIS DECLARATION OF CONFORMITY IS ISSUED UNDER THE EXCLUSIVE RESPONSIBILITY OF THE MANUFACTURER:



PEGO S.r.l. Via Piacentina 6/b, 45030 Occhiobello (RO) – Italy –

DENOMINAZIONE DEL PRODOTTO IN OGGETTO / DENOMINATION OF THE PRODUCT IN OBJECT

MOD.: PLUS100 PAN

IL PRODOTTO DI CUI SOPRA E' CONFORME ALLA PERTINENTE NORMATIVA DI ARMONIZZAZIONE DELL'UNIONE EUROPEA:
THE PRODUCT IS IN CONFORMITY WITH THE RELEVANT EUROPEAN HARMONIZATION LEGISLATION:

Direttiva Bassa Tensione (LVD):	2014/35/UE
<i>Low voltage directive (LVD):</i>	<i>2014/35/EU</i>
Direttiva EMC:	2014/30/UE
<i>Electromagnetic compatibility (EMC):</i>	<i>2014/30/EU</i>

LA CONFORMITA' PRESCRITTA DALLA DIRETTIVA E' GARANTITA DALL'ADEMPIMENTO A TUTTI GLI EFFETTI DELLE SEGUENTI NORME:
THE CONFORMITY REQUIRED BY THE DIRECTIVE IS GUARANTEED BY THE FULFILLMENT TO THE FOLLOWING STANDARDS:

Norme armonizzate: EN 60730-1:2016, EN 60730-2-9:2010, EN 61000-6-1:2007, EN 61000-6-3:2007
 European standards: EN 60730-1:2016, EN 60730-2-9:2010, EN 61000-6-1:2007, EN 61000-6-3:2007

IL PRODOTTO E' COSTITUITO PER ESSERE INCORPORATO IN UNA MACCHINA O PER ESSERE ASSEMBLATO CON ALTRI MACCHINARI PER COSTITUIRE UNA MACCHINA CONSIDERATE DALLA DIRETTIVA: 2006/42/CE "Direttiva Macchine".
THE PRODUCT HAS BEEN MANUFACTURED TO BE INCLUDED IN A MACHINE OR TO BE ASSEMBLED TOGETHER WITH OTHER MACHINERY TO COMPLETE A MACHINE ACCORDING TO DIRECTIVE: EC/2006/42 "Machinery Directive".

Firmato per nome e per conto di:
 Signed for and on behalf of:


Pego S.r.l.
 Lisa Zampini
 Procuratore Generale

Luogo e Data del rilascio:
 Place and Date of Release:

Occhiobello (RO), 08/01/2018

PLUS100 PAN CONNECTIONS DIAGRAM

A.2



Power section

1-2 Power supply 230VAC 50/60 Hz

Analogic inputs section

29-30 Evaporator sensor NTC

31-32 Humidity sensor 4-20 mA
(0-100Rh%) (32=V+ 31=Y)

27-28 Ambient sensor NTC

Digital inputs section

44-50 Fan overheat safety device

43-50 Humidifier alarm

42-50 Switch door

41-50 Compressor safety device

Outputs section (free-voltage contacts)

21-22 Alarm

23-24 Defrost

25-26 Dehumidification / air changeover

15-16 Stand-by

13-14 Humidification

11-12 Room light

9-10 Evaporator fans low speed (*)

7-8 Evaporator fans high speed (*)

5-6 Heat

3-4 Cold

TeleNET section:

39 A line on 2TWRS485

40 B line on 2TWRS485

(*)High speed: terminals 7-8 close, terminals 9-10 open
Low speed: terminals 7-8 open, terminals 9-10 close.



PEGO s.r.l.
Via Piacentina, 6/b 45030 Occhiobello ROVIGO - ITALY
Tel. +39 0425 762906 Fax +39 0425 762905
e.mail: info@pego.it – www.pego.it

AFTER-SALES ASSISTANCE CENTRE
Tel. +39 0425 762906 e.mail: tecnico@pego.it

Distributor: